



1731 Wierengo Dr. Muskegon, MI 49442 800.315.5799

©2018 ScentLok Technologies, Inc. | 072018

Model: OZRadial 400B (82918-090)

Input Vol: DC 5V/2A
Output Vol: DC 5V/2A

Power: 6.5W

Output: 400mg/h

Li-Power Battery: 13000mAh



82918-090 DC/12V





GETTING STARTED

Using the power of ozone, the **OZ**Radial 400B is built to remove unwanted odors from your cabins, closets, campers, etc. Use in unoccupied spaces only. Inside the package you will find the following: **OZ**Radial 400B, lanyard, wall plug, micro-USB charging cable, and this manual.

CHECKING THE BATTERY

Push either button once to activate the battery indicator lights.

- 4 lights = 100% power
- 2 lights = 50% power
 1 light = < 25% power
- 3 lights = 75% power

OPERATING INSTRUCTIONS

Regular Mode: Press either

 button twice to activate the device.

The lights will activate and the device will operate at normal speed. Press the button again to turn off.

Boost Mode: Quickly press both

■ buttons at once to activate the device.

The lights will activate and the device will run at a higher output.

Press the button again to turn off.

Regular Cycle Mode: Press & hold either

button for 3 seconds until the lights begin to oscillate. The device will run for 3 cycles of 30 minutes on / 30 minutes off, then it will power off.

Boost Cycle Mode: Press & hold both

■ buttons for 3 seconds until the lights begin to oscillate. The device will run for 3 cycles of 30 minutes on / 30 minutes of at a higher output then it will power off. Press either button again to turn off.

NOTE: After turning off, the unit has a cool down period of approximately 30 seconds

CHANGING MODES

Easily change modes by following the above instructions. To switch back to Regular Mode, you'll need to press either button 3 times.

CHARGING THE BATTERY*

- 1. Plug the included USB cable into the wall plug
- ${\bf 2.}$ Insert the small end of the cable into the micro-USB port.
- 3. Plug the power supply into a wall outlet.

NOTE: Regular & Boost modes will run continuously for the life of the battery, turn off if you do not want to use all of the battery at one time.

*Additional battery packs may be purchased separately.

IISE AS A POWER BANK

The **0Z**Radial 400B doubles as a mobile charger for your devices. Plug your device into the USB port on the front of the unit to automatically begin charging.

WARNING

This product should only be used according to the instructions in this owner's manual. If used other than what has been specified here, serious injury may occur.

The ozone unit is designed to be used in unoccupied spaces only. Upon entering a room that was treated with ozone you should ventilate the area allowing any possible lingering ozone to be cleared out. Never aim ozone directly into your face; it may cause eye irritation or other side effects.

If entering a room where the unit was in use and the room is still filled with ozone (0_3) has not fully reverted back to 0_2), it may cause mild headaches or irritation to the respiratory system. If this occurs, please exit the room immediately. If eyes continue to be irritated flush gently with water. If conditions continue seek medical attention

Keep away from children. Do not dismantle the ozone unit.

Depending on the concentration of bacteria and volume of odor, more than one cycle may be required to eradicate odors. Always allow for proper dissipation time between cycles. Exercise caution when using ozone on items with significant elastic or rubber content. Discontinue use on rubber or elastic items if you notice degradation or weakness to the structure of the items. Do not expose safety equipment to active odor destroyers. To prevent electric shock, do not plug or unplug unit with wet hands. Do not disassemble or insert items into unit. Doing so may cause damage or electric shock.

If you have any questions/concerns, please visit ScentLok.com or call us at 800.315.5799.

WARRANTY

We guarantee our product within one year of purchase. Please register at ScentLok.com/RegisterOZ. The guarantee does not cover equipment which has been damaged due to abuse, misuse or accident, such as:

- use of incorrect line voltages;
- failure to follow the operating instructions that are provided by ScentLok Technologies;
- improper or unauthorized repair; or
- fire, flood, "acts of God," or other contingencies beyond the control of ScentLok Technologies.