



ACTIVE ODOR DESTROYER

OZ RADIAL EZ USER MANUAL

Model: OZRadial EZ (4151090)	Power: 11W
Input Vol: DC 5V/2A	Li-Power Battery: 13000mAh
Output Vol: DC 5V/2A	

GETTING STARTED

Using the power of ozone, the **OZRadial EZ** is built to remove unwanted odors from your cabins, closets, campers, etc. Use in unoccupied spaces only. Inside the package you will find the following: **OZRadial EZ**, lanyard, wall plug, micro-USB charging cable, and this manual.

CHECKING THE BATTERY

When the device is on, the battery lights will be lit according to the chart below:

- 4 lights = 100% power
- 2 lights = 50% power
- 3 lights = 75% power
- 1 light = < 25% power

OPERATING INSTRUCTIONS

Regular Mode: Press the button once to activate. The light above "REG" will turn on and the device will operate at normal speed.

Max Mode: Press the button twice to activate. The light above "MAX" will turn on and the device will run at its highest output.

Regular Cycle Mode: Press the button three times to activate. The third light indicated with "REG" with a Cycle icon will turn on. The device will run for 3 cycles of 30 minutes on / 30 minutes off, then it will power off.

Max Cycle Mode: Press the button four times to activate. The fourth light labeled "MAX" with a Cycle icon will turn on. The device will run for 3 cycles of 30 minutes on / 30 minutes off at a higher output then it will power off.

TURNING OFF THE DEVICE

Press & hold the button for three seconds.

NOTE: After turning off, the unit has a cool down period of approximately 30 seconds

CHANGING MODES

Push the button once to change to the mode to the right of the one it is currently running. Repeat as many times as needed to reach the mode you desire.

NOTE: Regular & Max modes will run continuously for the life of the battery, turn off if you do not want to use all of the battery at one time.

CHARGING THE BATTERY*

1. Plug the included USB cable into the wall plug
2. Insert the small end of the cable into the micro-USB port, the charging indicator will light up red.
3. When fully charged the light will turn green and you should unplug the unit

If the device is not used frequently, it is still recommended to charge the battery at least once every three months.

*Additional battery packs may be purchased separately.

USE AS A POWER BANK

The **OZRadial EZ** doubles as a mobile charger for your devices. Plug your device into the USB port on the front of the unit to automatically begin charging.

WARNING

This product should only be used according to the instructions in this owner's manual. If used other than what has been specified here, serious injury may occur.

The ozone unit is designed to be used in unoccupied spaces only. Upon entering a room that was treated with ozone you should ventilate the area allowing any possible lingering ozone to be cleared out. Never aim ozone directly into your face; it may cause eye irritation or other side effects.

If entering a room where the unit was in use and the room is still filled with ozone (O₃ has not fully reverted back to O₂), it may cause mild headaches or irritation to the respiratory system. If this occurs, please exit the room immediately. If eyes continue to be irritated flush gently with water. If conditions continue seek medical attention. Keep away from children. Do not dismantle the ozone unit.

Depending on the concentration of bacteria and volume of odor, more than one cycle may be required to eradicate odors. Always allow for proper dissipation time between cycles. Exercise caution when using ozone on items with significant elastic or rubber content. Discontinue use on rubber or elastic items if you notice degradation or weakness to the structure of the items. Do not expose safety equipment to active odor destroyers. To prevent electric shock or damage, do not plug or unplug unit with wet hands. Do not disassemble, squeeze, strongly vibrate the device, or contact metal such as a key to avoid short circuit.

Store the device in ventilated, dry room temperature conditions. Keep the unit away from damp environments and fire sources to avoid danger. If the battery cell expands, leaks, or emits an odor, stop using the device immediately.

If you have any questions/concerns, please visit OZbyScentLok.com or call us at 800.315.5799.

WARRANTY

We guarantee our product within one year of purchase. Please register at OZbyScentLok.com/RegisterOZ. The guarantee does not cover equipment which has been damaged due to abuse, misuse or accident, such as:

- use of 3rd party chargers which may use incorrect line voltages;
- failure to follow the operating instructions that are provided by OZ;
- improper or unauthorized repair; or
- fire, flood, "acts of God," or other contingencies beyond the control of OZ.

4151190 DC/12V



SCENTLOK
TECHNOLOGIES