

GETTING STARTED

Using the power of ozone, the **OZ**Renew is built to seek and destroy unwanted odors. Use in unoccupied spaces only.

- Connect the **OZ**Renew to the power source.
- To turn on, press the button:
 - time runs 30 minutes & 1 indicator lights up
 times runs 60 minutes & 2 indicators light up
 times runs 90 minutes & 3 indicators light up
 times runs 120 minutes & 4 indicators light up
- To activate Cycle Clean[™] mode:
 Hold button down for 3 seconds indicator lights oscillate and the unit runs 30 minutes on & 30 minutes off for a total of 12 hours
- To turn off, press button once and the lights will turn off.

CHANGING MODES

In order to change modes you must first turn the unit off by pushing the button once, then you can activate whichever mode you want.

WARNING

The unit has a cool down period of approximately 1 minute after being turned off.

USING THE OZRENEW WITH BOOT PUCKS

The **OZ**Renew comes with a pair of boot pucks for you to deodorize your shoes. Connect one end of the transport tubing to the two ports on the bottom of the **OZ**Renew unit and the other end to the port on both pucks. Insert a puck into each shoe and let the ozone destroy the odors.

WARNING

This product should only be used according to the instructions in this owner's manual. If used other than what has been specified here, serious injury may occur.

The ozone unit is designed to be used in unoccupied spaces only. Upon entering a room that was treated with ozone you should ventilate the area allowing any possible lingering ozone to be cleared out. Never aim ozone directly into your face; it may cause eye irritation or other side effects.

If entering a room where the unit was in use and the room is still filled with ozone (O_3 has not fully reverted back to O_2), it may cause mild headaches or irritation to the respiratory system. If this occurs, please exit the room immediately. If eyes continue to be irritated flush gently with water. If conditions continue seek medical attention. Keep away from children. Do not dismantle the ozone unit.

Depending on the concentration of bacteria and volume of odor, more than one cycle may be required to eradicate odors. Always allow for proper dissipation time between cycles. Exercise caution when using ozone on items with significant elastic or rubber content. Discontinue use on rubber or elastic items if you notice degradation or weakness to the structure of the items. Do not expose safety equipment to active odor destroyers. To prevent electric shock, do not plug or unplug unit with wet hands. Do not disassemble or insert items into unit. Doing so may cause damage or electric shock.

If you have any questions/concerns, please visit **OZbyScentLok.com** or call us at 800.315.5799

WARRANTY

We guarantee our product within one year of purchase. Please register at **OZbyScentLok.com/Register0Z**. The guarantee does not cover equipment which has been damaged due to abuse, misuse or accident, such as:

- use of incorrect line voltages;
- failure to follow the operating instructions provided by OZ;
- improper or unauthorized repair; or
- fire, flood, "acts of God," or other contingencies beyond the control of OZ.

Model: OZRenew Power: (4151390) Input Vo

Power: 9W Input Vol: AC 110v/60Hz

CF HC RoHS

1731 Wierengo Dr., Muskegon, MI 49442 OZbyScentLok.com ©2019 Nexus Outdoors | 050619