



TECHNOLOGIES

1731 Wierengo Dr. Muskegon, MI 49442 800.315.5799

©2017 ScentLok Technologies, Inc. | 100917



82915-090 DC/12V





## **GETTING STARTED**

Using the power of ozone, the **0Z**100 is built to seek and destroy unwanted odors. Use in unoccupied spaces only.

- Connect the **0Z**100 to the power source and press the "ON/CYCLE" button.
- Use the "More" or "Less" buttons to set the indicated time. Unit will run for specified time then automatically turn off.
  - Each time you press "MORE" the timer increases by 5 minutes until you reach the 30 minute max
  - Each time you press "LESS" the timer decreases by 5 minutes until you reach 0 minutes
- Press "ON/CYCLE" again to activate Cycle Mode.
  Press "More" or "Less" for longer or shorter cycle times.
  The **02**100 will cycle indefinitely for the set time (e.g. 25 mins on and 25 mins off).
- Press "ON/CYCLE" again to turn off.

## WARNING

The unit has a cool down period of approximately 1 minute after being turned off.

## WARRANTY

We guarantee our product within one year of purchase. Please register at **ScentLok.com/RegisterOZ**. The guarantee does not cover equipment which has been damaged due to abuse, misuse or accident, such as:

- use of incorrect line voltages;
- failure to follow the operating instructions that are provided by ScentLok Technologies;
- improper or unauthorized repair; or
- fire, flood, "acts of God," or other contingencies beyond the control of ScentLok Technologies.

 Model:
 0Z100 (82913-090)

 Input Vol:
 AC100/60Hz

 Power:
 6W

 Output:
 100mg/h

## WARNING

This product should only be used according to the instructions in this owner's manual. If used other than what has been specified here, serious injury may occur.

The ozone unit is designed to be used in unoccupied spaces only. Upon entering a room that was treated with ozone you should ventilate the area allowing any possible lingering ozone to be cleared out.

Never aim ozone directly into your face; it may cause eye irritation or other side effects.

If entering a room where the unit was in use and the room is still filled with ozone ( $O_3$  has not fully reverted back to  $O_2$ ), it may cause mild headaches or irritation to the respiratory system. If this occurs, please exit the room immediately. If eyes continue to be irritated flush gently with water. If conditions continue seek medical attention.

Keep away from children. Do not dismantle the ozone unit.

Depending on the concentration of bacteria and volume of odor, more than one cycle may be required to eradicate odors. Always allow for proper dissipation time between cycles. Exercise caution when using ozone on items with significant elastic or rubber content. Discontinue use on rubber or elastic items if you notice degradation or weakness to the structure of the items. Do not expose safety equipment to active odor destroyers. To prevent electric shock, do not plug or unplug unit with wet hands. Do not disassemble or insert items into unit. Doing so may cause damage or electric shock.

If you have any questions/concerns, please visit ScentLok.com or call us at 800.315.5799