



RADIAL^{IQ}

GETTING STARTED

The **OZ Radial^{IQ}** was intelligently designed to deliver the right amount of ozone technology to destroy odors within the **OZChamber**, no guessing on amount or cycle length... just press the button once and let it run. Inside the package you will find the following: **Radial^{IQ}**, 12V DC power supply, vehicle power adapter, and the **OZChamber**.

OPERATING INSTRUCTIONS

1. Connect the power source to the bottom of the **Radial^{IQ}**.
2. Secure the unit within the center mesh pocket inside the **OZChamber** along the back side.
3. Press the top button once, the ring light will turn on and the unit will run for 30 minutes and then turn off.
4. To turn off manually, simply press the button again. The light will turn off & the fan will shut off after 30 second cool down.

WARRANTY

We guarantee our product within one year of purchase. Please register at ScentLok.com/RegisterOZ. The guarantee does not cover equipment which has been damaged due to abuse, misuse or accident, such as:

- use of incorrect line voltages;
- dropping the unit or submerging it in water;
- failure to follow the operating instructions that are provided by ScentLok Technologies;
- improper or unauthorized repair; or
- fire, flood, "acts of God," or other contingencies beyond the control of ScentLok Technologies.

WARNING

This product should only be used according to the instructions in this owner's manual. If used other than what has been specified here, serious injury may occur. The ozone unit is designed to be used in unoccupied spaces only. Upon entering a room that was treated with ozone you should ventilate the area allowing any possible lingering ozone to be cleared out. Never aim ozone directly into your face; it may cause eye irritation or other side effects.

If entering a room where the unit was in use and the room is still filled with ozone (O_3 has not fully reverted back to O_2), it may cause mild headaches or irritation to the respiratory system. If this occurs, please exit the room immediately. If eyes continue to be irritated flush gently with water. If conditions continue seek medical attention.

Keep away from children. Do not dismantle the ozone unit.

Exercise caution when using ozone on items with significant elastic or rubber content. Discontinue use on rubber or elastic items if you notice degradation or weakness to the structure of the items. Do not expose safety equipment to active odor destroyers. To prevent electric shock, do not plug or unplug unit with wet hands. Do not disassemble or insert items into unit. Doing so may cause damage or electric shock.

Please visit ScentLok.com with any questions.

HELPFUL HINTS

For best results, we recommend rotating your gear within the bag after 30 minutes and run the **Radial^{IQ}** a second time.

4151190 DC/5V

CE FC RoHS



SCENTLOK[®]
TECHNOLOGIES